

## PM70

### MAGNETIC CAR WIRELESS CHARGER



Thank you for choosing the Renline ExactFit phone mount. The PM70 is a magnetic wireless charger that can be added to any Renline ExactFit mount. The integrated aluminum alloy body allows for improved heat dissipation, so the charging performance is more stable. Can support MagSafe equipped phones, and non MagSafe phones with the addition of the adhesive-backed steel ring. Please read this manual carefully and keep it in a safe place for inspection.

#### Safety notes.

1. Please use qualified DC power adapter, otherwise it may cause instability.
3. Do not pull on the power cord to disconnect.
4. Do not disassemble PM70.
5. Do not use PM70 in high temperature environment.

#### FAQ

Q: The phone is not charging?

A1. The phone may not be aligned with the charging sensing area or there may be something blocking the charging area on the phone. Thick cases, credit cards, etc.

A2. Some USB outlets only output 500mA, which is not enough amperage to power your wireless charger. In this scenario we recommend using a power adapter such as a Cigarette lighter to USB adapter.

#### Technical Specifications

Model	PM70
Input	5V-2A / 9V-1.67A / 12V-2A(MAX)
Output	15W / 10W / 7.5W / 5W
Standard	Qi
Conversion Rate	≤80%
Dimension	∅57x30mm(Includes clip)
Weight	60g

